

VGA Driver Installation Guide

Version: V14.32.3 Update: 20090922

Trademarks

Some of the product names mentioned herein are used for identification purposes only and may be trademarks and/or registered trademarks of their respective owners.

Revision History

Version	Date	Description
V14.32.3	Aug. 2009	Release

Remark:

The below installation procedure is based on the version v14.32.3 and using Windows XP as an example, the installation procedure might slightly differ depending on the OS installed.

Driver Installation Procedure

Insert the Driver CD into your CD driver which is prior connected to the system then follow the installation instructions in the Setup Wizard.

Detail instruction as below:

1. You can find the drivers menu in the attached driver CD, please click the <Win2K,XP> in the <VGA> row. The procedure might differ depending on the OS you installed.

Driver list

Model name (Motherboard)	Function	OS	Note
	Chipset	Windows	Installation Guide
	Intel SATA AHCI	Windows driver	User manual
		Win2K, XP	Installation Guide
	VGA	Win2K, XP	IEGD driver Use for CRT output only
		Vista	
		Linux	
	Audio	Win2K, XP, 2003	Installation Guide
	• Realtek HD Codec	Vista	
		Linux	
	Windows XP update	Dual Core CPU	
		Chipset	
	Touch Screen auto detect / install program. Use for:		
	• ELO • POS Touch • POS Touch-HID • POS Touch+	Windows	Read Me
	Touch Screen	DOS	
	• ELO Touch	Windows	v463 Installation Guide
		Windows/Alpha	v481 (alpha driver)
		Linux	
	Touch Screen	DOS	
	• POSTouch	Windows	Installation Guide
		Linux	
	PCI-E 1000Mb LAN	DOS	
	• Realtek RTL8111	Win9X, ME, 2K, XP	Installation Guide
		Vista	
		Linux	
	Mini PCI-E IEEE802.11b/g/n Wireless LAN	Win2K, XP	
	• WS32L • WS33N	Vista	
		WinXP 64bit	
		Vista 64bit	
	BIOS flash utility	DOS	
	Hardware Monitor	Windows	
	Watch Dog Timer (WDT) demo tool	DOS	With C language source code
		Windows	With VB language source code
		Programming guide	
	Cash Drawer controller test utility (use I/O port 0x48C)	DOS	With C language source code
	Finger Print Module	Windows	
	• U4500	SDK for Windows and Linux	
		Demo and Test program (Windows)	Installation and User Guide
	Magnetic Card Reader		
	• S64 series	Windows	Utility
	Magnetic Card Reader		
	• IDMB series	Windows	Utility
	P07303 series 20*2 VFD Customer Display		
	• Demo tool	DOS	User's manual V1.7
	P07303 series 20*2 VFD Customer Display		
	• USB driver	Win98, ME, 2K, XP, 2003	
		Vista	
		Linux	


2. Double click on the folder <v14.32.3>.




3. Double click to run <win2k_xp14323.exe>.



4. Click <Next> to run the InstallShield Wizard.




5. Files are extracting.




6. Click <Next> to the Setup Program.




7. Click <Yes> to accept the License Agreement.



8. Click <Next>.



9. Setup program is running.



10. Click <Next> to continue.



11. Select <Yes, I want to restart this computer now>, then click <Finish>.

